Top-of-Pole Mount (TPM)



Weight: 0.00kg
Dimensions: 0.00cm x 0.00cm x 0.00cm

Description

The **Top-of-Pole Mount (TPM)** is designed to install quickly and provide a secure mounting structure for PV modules on a single pole. The module specific design reduces the number of components and provides for an easier assembly. The TPM utilizes high strength welded steel components and corrosion resistant hardware for long term flexibility. Seasonal adjustability for maximizing production is provided by six different tilt-angle settings and is a single person operation.

Design Your Next Project

TPM Design Tool

- Specify the proper TPM for your application.
- Includes foundation drawings and specifications.

Get Started!

Features

MAXIMUM STRENGTH - DURABLE DESIGN

- Standard mounts designed to withstand 90 MPH wind zones
- MIG welded steel strong backs and mounting sleeves
- 6000 series structural aluminum mounting rails
- Stainless steel module mounting hardware
- Zinc plated rack assembly hardware

APPLICATION FLEXIBILITY

- Available in multiple sizes - supporting 1 through 24 modules
- Installs over standard Schedule 40 or 80 rigid steel pipe (installer supplied)
- 15° to 65° tilt angle settings (10° increments)
- Mount up to 4.1kW on a single pole

OPTIONS / UPGRADES

- High wind version - 130 MPH exposure
- Hot dip galvanized or powder coated finish on steel components
- Anodized module rails
- Stainless steel rack assembly hardware package
- Tamper-resistant module mounting hardware package

Documentation
Sell Sheet
Top-of-Pole Mounts

Hardware List Pricing
TPM Pricing and Selection Guide --New Pricing effective January 1, 2019

Request a Quote/Information
Request for Quote Form
TPM Configuration Design Tool

Product Brochure
Quality Mounting Hardware Solutions for the PV Solar Industry

Application Information
TPM Addendum - Installing Support Bars
Top Clamping Modules TPM Rack Installation Supplement
TPM1 Type A-G Assembly Instructions
TPM1 Type H Assembly Instructions

TPM2 Type A-B Assembly Instructions
TPM2 Type C-H Assembly Instructions
TPM3 Type A-C Assembly Instructions
TPM3 Type D Assembly Instructions
TPM3 Type E-H Assembly Instructions
TPM3 for 3 Kaneka Modules Assembly Instructions
TPM4 Type A-B Assembly Instructions
TPM4 Type C Assembly Instructions
TPM4 Type D-G Assembly Instructions
TPM4 Type H Assembly Instructions
TPM6 Type A-E Assembly Instructions
TPM6 Type F-G Assembly Instructions
TPM8 Type A-B Assembly Instructions
TPM8 Type C Assembly Instructions
TPM8 Type D-H Assembly Instructions
TPM9 Type C-H Assembly Instructions
TPM10 Type A-B Assembly Instructions
TPM10 Type C-G Assembly Instructions
TPM10 Type H Assembly instructions
TPM12 Type A-C Assembly Instructions
TPM12 Type D-G Assembly Instructions
TPM12 Type H Assembly Instructions
TPM14 Type A-C Assembly Instructions
TPM14 Type D-G Assembly Instructions
TPM15 Type C-D Assembly Instructions
TPM15 Type E-G Assembly Instructions
TPM16 Type A-B Assembly Instructions
TPM16 Type C Assembly Instructions
TPM16 Type D-F Assembly Instructions
TPM18 Type C Assembly Instructions
TPM18 Type D-F Assembly Instructions
TPM46 Enphase M215 Inverter on a TPM Rack

Product Gallery

