


COAX DROP WIRE CLOSURE

Catalog Number 8006590

Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED™ product before application.



2 Gel-Filled Closure Halves

PREFORMED LINE PRODUCTS

P.O. Box 91129, Cleveland, Ohio 44101 (440) 461-5200 www. preformed.com

email: inquiries@preformed.com

1.00 GENERAL INFORMATION

1.01 The Coax Drop Wire Closure is available in two sizes. This large closure (Catalog #8006590) accepts coax drops to .45" in diameter and associated connectors (RG7, RG11). Closures must be replaced after reentry.

2.04 Coax Drop Wire Closure is ready for burial. (Figure 3)



FIGURE 3 - COMPLETED APPLICATION

2.00 COAX DROP PREPARATION

- **2.01** Prepare coax drop with associated connectors as per company practices.
- 2.02 Place center of coupler between coupler retaining posts. (Figure 1)




FIGURE 1 - PLACE COUPLER

2.03 Take top half of closure and line up with bottom half to mate snaps with holes. Press until top half clicks into place. (Figure 2)




FIGURE 2 - SNAP TOGETHER CLOSURE

3.00 SAFETY CONSIDERATIONS

- 3.01 This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual. Failure to follow these procedures may result in personal injury.
- 3.02 When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.
- 3.03 For proper performance and personal safety, be sure to select the proper size PREFORMED™ Product before application.
- 3.04 This product is intended for use by trained technicians only. This product should not be used by anyone who is not familiar with and not trained to use it.