




CUSHION-GRIP® Spacer Damper with Bolted Arm

Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED product before application.



NOMENCLATURE

Step #1

OPEN KEEPERS


Back out each keeper bolt until disengaged from the arm.



Step #2


POSITION SPACER DAMPER ON CONDUCTORS

Position Spacer Damper on conductors noting the orientation (up arrow) molded on the frame. Be sure that the Spacer Damper sits squarely on each conductor.





Step #3a CLOSE KEEPERS

Close each keeper around the conductor and tighten the bolts using an "impact style" wrench or tool.




NOTE:

For Spacer Dampers with break-away bolts, tighten bolt until shear head snaps off to ensure proper torque.




Step #3b

After installation, the final torque at each bolt should be checked with a calibrated torque wrench to ensure a torque of 40 ft.-lbs has been applied. Each conductor should be held firmly in the cushions. The spacer damper should not move if pulled by hand.



Step #3c Completed application.



NOTE: Each bolt can only be installed a maximum of three times before being replaced.
Break-Away Bolt – Single Installation ONLY.

SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual. **FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.**

Do not modify this product under any circumstances.

This product is intended for use by trained technicians only. **This product should not be used by anyone who is not familiar with, and not trained to use it.**

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.

For proper performance and personal safety, be sure to select the proper size PREFORMED product before application.

PREFORMED products are precision devices. To insure proper performance, they should be stored in cartons under cover and handled carefully.



PREFORMED LINE PRODUCTS

P.O. Box 91129, Cleveland, Ohio 44101 • 440.461.5200 • www.preformed.com • e-mail: inquiries@preformed.com

SP3041-3