





CUSHION-GRIP™ Twin Spacer


Be sure to read and completely understand this procedure before applying product. Be sure to select the proper PREFORMED™ product before application.

Step #1 Preparation

Back out break-away bolt by hand until the two frame halves are free to move.





Step #2 Slide frame halves apart enough to allow the conductor to be positioned within the elastomer inserts.



Step #3 Placement

Position the spacer so that it is perpendicular to the longitudinal axis of the conductors.





Step #4 Slide the frame halves together as far as possible.


NOTE: Ensure that the single solid line on the sides of the top frame half is within the wider bar on the sides of the bottom frame half.



PLP Tip: Tightening the bolt slightly by hand will prevent the frame halves from moving apart.




Step #5 Tighten the break-away bolt to fully engage the spacer on the conductors.



Step #6 Completion

Continue to tighten the break-away bolt until the upper head breaks off. This will insure the proper installation torque.

Properly dispose of the upper head of the bolt and the stainless steel pin.



SAFETY CONSIDERATIONS

This application procedure is not intended to supersede any company construction or safety standards. This procedure is offered only to illustrate safe application for the individual.

FAILURE TO FOLLOW THESE PROCEDURES MAY RESULT IN PERSONAL INJURY OR DEATH.

Do not modify this product under any circumstances.

This product is intended for use by trained technicians only. **This product should not be used by anyone who is not familiar with, and not trained to use it.**

When working in the area of energized lines, extra care should be taken to prevent accidental electrical contact.

For proper performance and personal safety, be sure to select the proper size PREFORMED™ product before application.

PREFORMED products are precision devices. To insure proper performance, they should be stored in cartons under cover and handled carefully.



PREFORMED LINE PRODUCTS

P.O. Box 91129, Cleveland, Ohio 44101 • 440.461.5200 • www.preformed.com • e-mail: inquiries@preformed.com

SP3005-1